



Linux Port to LatticeMico32 System Quick-Start Guide

Lattice Semiconductor Corporation
5555 NE Moore Court
Hillsboro, OR 97124
(503) 268-8000

February 2008

Copyright

Copyright © 2008 Lattice Semiconductor Corporation.

This document may not, in whole or part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from Lattice Semiconductor Corporation.

Trademarks

Lattice Semiconductor Corporation, L Lattice Semiconductor Corporation (logo), L (stylized), L (design), Lattice (design), LSC, E²CMOS, Extreme Performance, FlashBAK, flexiFlash, flexiMAC, flexiPCS, FreedomChip, GAL, GDX, Generic Array Logic, HDL Explorer, IPexpress, ISP, ispATE, ispClock, ispDOWNLOAD, ispGAL, ispGDS, ispGDX, ispGDXV, ispGDX2, ispGENERATOR, ispJTAG, ispLEVER, ispLeverCORE, ispLSI, ispMACH, ispPAC, ispTRACY, ispTURBO, ispVIRTUAL MACHINE, ispVM, ispXP, ispXPGA, ispXPLD, LatticeEC, LatticeECP, LatticeECP-DSP, LatticeECP2, LatticeECP2M, LatticeMico8, LatticeMico32, LatticeSC, LatticeSCM, LatticeXP, LatticeXP2, MACH, MachXO, MACO, ORCA, PAC, PAC-Designer, PAL, Performance Analyst, PURESPEED, Reveal, Silicon Forest, Speedlocked, Speed Locking, SuperBIG, SuperCOOL, SuperFAST, SuperWIDE, sysCLOCK, sysCONFIG, sysDSP, sysHSI, sysI/O, sysMEM, The Simple Machine for Complex Design, TransFR, UltraMOS, and specific product designations are either registered trademarks or trademarks of Lattice Semiconductor Corporation or its subsidiaries in the United States and/or other countries. ISP, Bringing the Best Together, and More of the Best are service marks of Lattice Semiconductor Corporation.

HyperTransport is a licensed trademark of the HyperTransport Technology Consortium in the U.S. and other jurisdictions.

Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

Disclaimers

NO WARRANTIES: THE INFORMATION PROVIDED IN THIS DOCUMENT IS "AS IS" WITHOUT ANY EXPRESS OR IMPLIED WARRANTY OF ANY KIND INCLUDING WARRANTIES OF ACCURACY, COMPLETENESS, MERCHANTABILITY, NONINFRINGEMENT OF INTELLECTUAL PROPERTY, OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT WILL LATTICE SEMICONDUCTOR CORPORATION (LSC) OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OF OR INABILITY TO USE THE INFORMATION PROVIDED IN THIS DOCUMENT, EVEN IF LSC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME JURISDICTIONS PROHIBIT THE EXCLUSION OR LIMITATION OF CERTAIN LIABILITY, SOME OF THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

LSC may make changes to these materials, specifications, or information, or to the products described herein, at any time without notice. LSC makes no commitment to update this documentation. LSC reserves the right to discontinue any product or service without notice and assumes no obligation

to correct any errors contained herein or to advise any user of this document of any correction if such be made. LSC recommends its customers obtain the latest version of the relevant information to establish, before ordering, that the information being relied upon is current.

Type Conventions Used in This Document

| Convention | Meaning or Use |
|-----------------------|---|
| Bold | Items in the user interface that you select or click. Text that you type into the user interface. |
| <i><Italic></i> | Variables in commands, code syntax, and path names. |
| Ctrl+L | Press the two keys at the same time. |
| <i>Courier</i> | Code examples. Messages, reports, and prompts from the software. |
| ... | Omitted material in a line of code. |
| . | Omitted lines in code and report examples. |
| [] | Optional items in syntax descriptions. In bus specifications, the brackets are required. |
| () | Grouped items in syntax descriptions. |
| { } | Repeatable items in syntax descriptions. |
| | A choice between items in syntax descriptions. |



Contents

| | |
|---|----------|
| Linux Port to LatticeMico32 System Quick-Start Guide | 1 |
| Prerequisites | 2 |
| Lattice Semiconductor ispLEVER Tools | 2 |
| TFTP Server | 2 |
| ispVM System | 2 |
| Im32-elf-gdb and TCP2JTAGVC2 | 2 |
| Remote Serial Console | 3 |
| Binary Distribution Tarball | 3 |
| Setting Up the Build Environment | 3 |
| Starting the LatticeMico32 System SDK Shell | 3 |
| Unpacking the Distribution Tarball | 4 |
| Tarball Contents | 4 |
| Providing Required Files Through TFTP | 5 |
| Downloading the Bitstream to the FPGA | 5 |
| Components and Memory Layout of the Bitstream | 5 |
| Programming the Bitstream | 6 |
| Loading U-Boot | 6 |
| Setting Up the Hardware | 6 |
| Setting Up the Remote Serial Console | 7 |
| Loading U-Boot into RAM by Using JTAG and GDB | 9 |
| Configuring the Network Interface | 12 |
| Writing U-Boot into Flash Memory | 16 |
| Starting U-Boot from Flash Memory | 17 |
| Booting the Linux Port to LatticeMico32 | 17 |
| Setting Kernel Boot Options in U-Boot | 18 |
| Loading the Kernel and the Initial RAM Disk Through TFTP | 19 |
| Booting the Kernel | 21 |
| Programming the Images into Flash Memory (Optional) | 22 |
| Testing the Setup | 27 |
| telnet | 28 |
| Userland Application | 28 |

| | |
|-------------------------------------|-----------|
| HTTP Server | 28 |
| LED Switch Web Application | 30 |
| LED Switch Command-Line Application | 30 |
| More Information | 32 |
| Index | 33 |



Linux Port to LatticeMico32 System Quick-Start Guide

This guide serves as a tutorial to enable you to set up and use a fully functional Linux-based environment on a LatticeECP2-50-based development board in approximately 60 minutes by using a WindowsXP/Cygwin or a Linux environment as host platform. It starts by showing you how to set up the environment and concludes by demonstrating how to test and evaluate Linux on LatticeMico32. You will use the pre-built binaries of the demonstration distribution and a pre-generated binary platform bitstream.

Each section in this guide depends on successful completion of the previous section.

Prerequisites

The following prerequisites must be met before you proceed with setting up the environment.

Lattice Semiconductor ispLEVER Tools

The ispVM and LatticeMico32 System tools must be installed and functioning on your system.

TFTP Server

The TFTP server is used to load the binaries onto the board as soon as U-Boot is available.

This guide assumes that a working TFTP server is available at a known IP address. Use the IP address of 192.168.0.1 as the default for this server.

You can download TFTP server software from the following Web sites:

Note

These links are suggestions, not recommendations.

- ◆ <http://code.google.com/p/tftpgui/>
- ◆ <http://pagesperso-orange.fr/philippe.jounin/tftpd32.html>
- ◆ <http://sourceforge.net/projects/tftp-server/>
- ◆ http://www.wintftp.com/index.php?option=com_frontpage&Itemid=1

If your development machine has a Linux operating system, it should also include an TFTP server.

For information on setting up TFTP by using Cygwin, click on the following link: https://linuxlink.timesys.com/docs/windows_tftp.

ispVM System

To program the pre-generated bitstream to the flash memory on the development board, you must install ispVM System and ensure that it is functional.

Im32-elf-gdb and TCP2JTAGVC2

Lm32-elf-gdb and TCP2JTAGVC2 are required for copying and programming the U-Boot boot loader to the board. These applications are part of the ispLEVER and LatticeMico32 System tool suites.

Also part of this tool suite is the LatticeMico32 System SDK shell on Windows, which you will use to unpack the binary distribution tarball and start Im32-elf-gdb.

Remote Serial Console

An application for setting up a remote serial console over a RS-232 serial connection is needed for configuring and using U-Boot and Linux in an early stage. The PuTTY application, which you can obtain at <http://www.chiark.greenend.org.uk/~sgtatham/putty>, is recommended and is used in this guide for this purpose. You must use version 0.59 or later. Alternatively, you can use HyperTerminal, which is shipped with Windows 95, Me, 2000, and XP. On Linux, you can also use Picocom.

Binary Distribution Tarball

The binary distribution is delivered as a tar.gz tarball named `lm32linux-<yyyymmdd>bin.tar.gz`. It is usually identifiable by the “bin” appellation at the end of the file name. This tarball is required because it contains the pre-built U-Boot, the Linux LatticeMico32 binaries and images, and the pre-generated bitstream. The bitstream is identical to the fully featured bitstream (`ecp250full` or `ECP250full_config`) shipped with the sources (see “Pre-Generated Bitstreams” in the *Linux Port to LatticeMico32 System Reference Guide*).

Setting Up the Build Environment

Now that all the prerequisites are met, you can set up the build environment.

Starting the LatticeMico32 System SDK Shell


This step applies only to Windows. If you are using Linux, you can use any shell terminal window.

To start the LatticeMico32 System SDK shell:

- ◆ Start the LatticeMico32 System SDK shell by clicking **Start > All Programs > Lattice Semiconductor > Accessories > LatticeMico32 System SDK Shell**.

The LatticeMico32 System SDK shell now appears, as shown in Figure 1.

Figure 1: LatticeMico32 System SDK Shell



Unpacking the Distribution Tarball

To unpack the distribution tarball:

1. Copy the binary distribution tarball to the root directory of the SDK shell. Assuming that the tarball is located in C:\Downloads\ and is named lm32linux-<yyyymmdd>.tar.gz, you would use the following command:

```
cp C:\\Downloads\\lm32linux-<yyyymmdd>.tar.gz /
```

2. Unpack the tarball by typing the following command:

```
tar -xzf lm32linux-<yyyymmdd>.tar.gz
```

3. Now move to the newly created directory called lm32linux-<yyyymmdd>.bin and list its contents:

```
cd lm32linux-<yyyymmdd>.bin
ls
```

These transactions are shown in Figure 2.

Figure 2: Unpacking the Distribution Tarball

```
LatticeMico32 System Cygwin Shell
[/] $ cp C:\\Downloads\\lm32linux-YYYYMMDDbin.tar.gz /
[/] $ ls
bin          cygwin.bat  etc         lm32linux-YYYYMMDDbin.tar.gz  tmp  var
cygdrive    cygwin.ico  lib         proc                          usr
[/] $ tar -xzf lm32linux-YYYYMMDDbin.tar.gz
[/] $ ls
bin          cygwin.bat  etc         lm32linux-YYYYMMDDbin        proc  usr
cygdrive    cygwin.ico  lib         lm32linux-YYYYMMDDbin.tar.gz tmp   var
[/] $ cd lm32linux-YYYYMMDDbin
[/lm32linux-YYYYMMDDbin] $ ls
MSBplatform.msb  initrd.img  u-boot      vmlinux
README           platform.bit u-boot.bin  vmlinux.img
[/lm32linux-YYYYMMDDbin] $
```

Tarball Contents

The distributed tarball contains the following files:

- ◆ README, which is a text file that describes the tarball contents and contains a quick-start guide
- ◆ platform.bit, which contains the pre-generated binary bitstream that will be programmed into the board by ispVM System
- ◆ MSBplatform.msb, which is the LatticeMico32 Mico System Builder .msb file from which the platform.bit file was generated
- ◆ u-boot.bin, which is the stripped U-Boot binary to be programmed into the flash memory
- ◆ u-boot, which is the unstripped U-Boot binary for optional JTAG debugging by GDB. This binary is used in the following sections for loading the stripped U-Boot into flash memory.

- ◆ vmlinux.img, which is the stripped and compressed Linux LatticeMico32 kernel image for U-Boot
- ◆ vmlinux, which is the unstripped Linux LatticeMico32 kernel binary for JTAG debugging by GDB. (This guide does not cover this topic.)
- ◆ initrd.img, which is the ext2 initial RAM disk (file system) image.

Providing Required Files Through TFTP

Through the TFTP server, you must provide the following files from the tarball for downloading onto the board:

- ◆ u-boot.bin
- ◆ vmlinux.img
- ◆ initrd.img

To provide files from the tarball:

1. Create a directory named lm32linux in the TFTP server's root directory and copy these three files to this newly created directory. On Linux, you may need superuser permissions.
2. After this, you can obtain the files by using the following command:

```
tftp 192.168.0.1 get <filename> /lm32linux/<filename> .
```

Downloading the Bitstream to the FPGA

A pre-generated hardware bitstream, platform.bit, is included in the distributed binary release tarball. The provided pre-built U-Boot was configured for this hardware setup. This bitstream must be programmed to the FPGA on the present LatticeECP2-50-based board.

Components and Memory Layout of the Bitstream

Table 1 shows the supported components and the memory layout of the bitstream that was built from the provided MSBplatform.msb file.

Table 1: Components and Memory Layout

| MSB Name | Component | Memory (Size in Bytes) | Mapped to Driver |
|-----------|-----------|------------------------|------------------|
| LM32 | CPU | – | CPU |
| flash | Flash | 0x04000000 (33554432) | FLASH |
| ddr_sdram | DDR RAM | 0x08000000 (67108864) | DDR_SDRAM |
| uart | UART | 0x80000000 | UART |
| timer0 | Timer | 0x80002000 | TIMER |

Table 1: Components and Memory Layout

| MSB Name | Component | Memory (Size in Bytes) | Mapped to Driver |
|----------------|------------------------|------------------------|------------------|
| timer1_devonly | Timer | 0x80010000 | TIMER |
| timer2_devonly | Timer | 0x80012000 | TIMER |
| ts_mac_core | Tri-Speed Ethernet MAC | 0x80008000 | TRISPEEDMAC |
| LED | LED | 0x80004000 | LEDS |
| LED_7Segs | 7-Segment LED | 0x80006000 | 7SEG |

Programming the Bitstream

Programming the distributed hardware bitstream, platform.bit, to the FPGA is performed with the ispVM System tool. On Windows, you can start this tool by selecting **Start > All Programs > Lattice Semiconductor > Accessories > ispVM System**. On Linux, start it by running the following script on the command line:

```
<ispLEVER_install_path>/ispvmsystem/ispvm
```

See “Task 4: Downloading the Hardware Bitstream to the FPGA” in the *LatticeMico32 Tutorial* for information on downloading the bitstream to the FPGA on the board. You can obtain this document through the [Lattice Semiconductor Web site](#).

Loading U-Boot

After programming the bitstream to the FPGA, you must load U-Boot onto the board and into the flash memory. You will use GDB, the TFTP server, and PuTTY to do this.

For more information on U-Boot, go to the following Web site:

<http://www.denx.de/wiki/UBoot>

Setting Up the Hardware

You must first set up the hardware and establish the connection between the board and the host:

1. Connect the JTAG interface and the serial interface (RS-232) to the host computer.
2. Power up the board, if you have not already.

Setting Up the Remote Serial Console

An application for setting up a remote serial console over a RS-232 serial connection is used to communicate with the board as soon as U-Boot is uploaded in order to set it up.

The following two sections describe how to configure PuTTY and HyperTerminal for this task. Only one of the two programs is needed, and although it is recommend that you use PuTTY (the accompanying screenshots will show the output in PuTTY), you can use HyperTerminal without limitation as well.

Setting Up PuTTY



It is recommended that you use PuTTY as the remote serial application. You can obtain it free at <http://www.chiark.greenend.org.uk/~sgtatham/putty/>. You must use version 0.59 or later.

To set up PuTTY:

1. Download the putty.exe file and run the program.
An installation of the software is not required.
Immediately after you start the application, the PuTTY Configuration dialog box appears.
2. In the PuTTY Configuration dialog box, do the following:
 - a. Choose **Serial** as connection type.
 - b. In the Serial Line box on Windows, specify the COM port to which the board is connected. On Linux, the default serial port is /dev/ttyS0, and you must have "rw" permission.
 - c. In the Speed box, set the baud rate to **115200**.
 - d. On the Category menu at the left, choose **Serial** (at the bottom of the list), and change the flow control setting to **None**.

The PuTTY Configuration dialog boxes on Windows are shown in Figure 3.

Figure 3: PuTTY Setup



- e. If you want to save your settings, switch back to Session in the Category box; enter a configuration identification name, such as LatticeMico32, in the Saved Sessions box; and click **Save** in the first dialog box.
- f. Click **Open** to establish the connection to the board.

The setup is now complete.

Setting Up HyperTerminal in Windows

Although it is recommended that you use PuTTY, you can also use HyperTerminal on Windows.

To set up HyperTerminal:

1. You can start HyperTerminal by selecting **Start > All Programs > Accessories > Communications > HyperTerminal**.

If the application is not installed on your computer, you can find it on the Windows installation CD. You can install it by using the Add or Remove Programs tool in the Control Panel.

2. After starting HyperTerminal, create a new connection. Provide a name that describes the connection, such as LatticeMico32, and use the COM port to which the board is connected (that is, "Connect using" should be set to one of the COM ports).
3. In the following dialog box, do the following:
 - a. Select a baud rate (that is, bits per second) of **115200**.
 - b. Select **8** data bits.
 - c. Set parity to **None**.
 - d. Set stop bit to **1**.
 - e. Set the flow control to **None**.
 - f. Confirm your settings by clicking **OK**.

Loading U-Boot into RAM by Using JTAG and GDB

Before writing U-Boot into flash memory, you must load it into RAM and start it from there.

To load U-Boot into RAM and start it:

1. If you are using Windows, start a new LatticeMico32 System SDK shell, as described in "Starting the LatticeMico32 System SDK Shell" on page 3. If you are using Linux, open a new shell terminal window.

Now you should have two shells opened, where the current working directory of the first shell is `/lm32linux-<yyyymmdd>bin/`, and the current working directory of the second one is `/`.

2. If you are using Windows, type **TCP2JTAGVC2** in the second shell (current directory `/`) window and press **Enter** to start the application.

If you are using Linux, perform the following steps:

- a. Make sure that a USB driver is installed (refer to `<isptools_install_dir>/ispvmsystem/ispVMLinuxInstallation.pdf` for information).
- b. In a c-shell, source `setup_lv.csh` located in `<isp_lever_install_dir>/ispcpd/bin` directory.

- c. Source LatticeMico32.csh (. ./ LatticeMico32.sh on the Korn shell), which is located in the `<lm32_install_dir>` directory.
- d. Go to `<lm32_install_dir>/gtools/bin` and execute by entering **TCP2JTAGVC2**.


This server, which is started in background, provides a proxy between the JTAG interface and the GDB client.

3. In the first shell (current directory `/lm32linux-<yyyymmdd>bin/`) window on Windows, start GDB for the LatticeMico32 architecture by executing **lm32-elf-gdb**. If you are using Linux, start GDB for the LatticeMico32 architecture by executing the following command in the first shell terminal window:

```
<lm32_install_dir>/gtools/bin/lm32-elf-gdb
```

After GDB has finished, the two shell windows in Windows should look something like those shown in Figure 4.


Figure 4: lm32-elf-gdb and TCP2JTAGVC2 Windows



4. In the first shell window, enter the **target remote localhost:1000** GDB command to establish a connection between the board and the TCP2JTAGVC2 proxy. For Linux, at the GDB command enter **target remote localhost:5000**.

The shell in which TCP2JTAGVC2 was started displays debug information if the connection was established successfully, as shown in Figure 5.

Figure 5: Im32-elf-gdb and TCP2JTAGVC2 Connecting



The figure consists of two screenshots of a Cygwin shell window titled "LatticeMico32 System Cygwin Shell".

The top screenshot shows the execution of the `Im32-elf-gdb` command. The output includes the GNU gdb 6.5 version, copyright information, and the configuration for remote debugging on localhost:1000. The prompt is `(gdb) _`.

```
LatticeMico32 System Cygwin Shell
L:/Im32linux-YYYYMMDDbin1 $ Im32-elf-gdb
GNU gdb 6.5
Copyright (C) 2006 Free Software Foundation, Inc.
GDB is free software, covered by the GNU General Public License, and you are
welcome to change it and/or distribute copies of it under certain conditions.
Type "show copying" to see the conditions.
There is absolutely no warranty for GDB. Type "show warranty" for details.
This GDB was configured as "--host=i686-pc-cygwin --target=lm32-elf".
(gdb) target remote localhost:1000
Remote debugging using localhost:1000
0x00000314 in ?? <
(gdb) _
```

The bottom screenshot shows the execution of the `TCP2JTAGVC2` command. The output displays the JTAGServer listening on port 4000, the connection to the debugger at 127.0.0.1:1076, and a list of system configuration parameters for the target CPU.

```
LatticeMico32 System Cygwin Shell
L/1 $ TCP2JTAGVC2
11/09/07 17:43:24 JTAGServer listening on port 4000.
L/1 $ Connected to debugger at 127.0.0.1:1076
Connected to target CPU:
CFG CSR: 0x440209cf
Multiply enabled: TRUE
Divide enabled: TRUE
Barrel shift enabled: TRUE
Sign extend enabled: TRUE
User enabled: FALSE
Cycle counter enabled: FALSE
D-Cache enabled: TRUE
I-Cache enabled: TRUE
Debug enabled: TRUE
HW debug enabled: FALSE
ROM debug enabled: FALSE
JTAG UART enabled: TRUE
Interrupts: 32
Breakpoints: 0
Watchpoints: 0
Revision: 1
```

5. Enter the **load ./u-boot** GDB command to upload the U-Boot JTAG debugging executable to the board using its JTAG interface.
6. Once the executable has been loaded into memory, enter the the **c** (shorthand for continue) GDB command, which starts U-Boot from RAM.

PuTTY, which you have already configured, should show the output of the U-Boot boot loader start-up sequence and should present you the U-Boot command-line interface, as shown in Figure 6.

Figure 6: U-Boot Output and CLI in PuTTY

```

COM3 - PuTTY
U-Boot 1.2.0 (Oct 29 2007 - 16:24:12) [Theobroma Systems]

LatticeMico32 board configuration:
Device | Base Address | Additional information
-----|-----|-----
CPU 0 | | Frequency: 75000000 Hz
Flash 0 | 0x04000000 | Size: 33554432 (32 MB)
DDR SDRAM 0 | 0x08000000 | Size: 67108864 (64 MB)
Timer 0 | 0x80010000 |
Timer 1 | 0x80012000 |
Timer 2 | 0x80014000 |
UART 0 | 0x80000000 | Baud Rate: 115200
LEDs 0 | 0x80004000 |
75Segment 0 | 0x80006000 |
TriSpeedMAC 0 | 0x80008000 |

LM32 configuration options:
Hardware multiplier: enabled
Hardware divider: enabled
Hardware barrel-shifter: enabled
Sign-extension instructions: disabled
Cycle counter CSR: disabled
Instruction cache: enabled
Data cache: enabled

l32mac version 0x10000 @ 0x80008000
l32MAC#0
In: serial
Out: serial
Err: serial
l32#
  
```

Configuring the Network Interface

Now that you have started the U-Boot for JTAG debugging, the “real” U-Boot should be programmed into flash memory. But first you must configure the board’s network interface through U-Boot to be able to obtain the U-Boot binary using the TFTP server.

Setting Environment Variables in U-Boot

Set environment variables in U-Boot with the `setenv` command, using the following syntax:

```
setenv <variables> <value>
```

See “Configuring the Network Interface in U-Boot” on page 23 of the *Linux Port to LatticeMico32 System Reference Guide* for information on the environment variables that you can use to configure the network interface in U-Boot.

For example, to set the `ipaddr` variable to 192.168.0.10, you would type this:

```
setenv ipaddr 192.168.0.10
```

You can permanently save environment variables by using the `saveenv` command, which writes the configuration to a protected sector in the flash memory of the board and is loaded each time U-Boot starts.

Checking Environment Variables in U-Boot

You can use the `printenv` and `bdinfo` commands on the console command line to check the U-Boot settings:

printenv Prints all set environment variables. The syntax is as follows:

```
printenv
```

Here is an example:

```
lm32# printenv

bootdelay=5
baudrate=115200
ethaddr=12:34:56:78:ab:cd
ethact=lm32MAC#0
filesize=1000040
fileaddr=8000000
stdin=serial
stdout=serial
stderr=serial
ipaddr=192.168.0.100
netmask=255.255.255.0
serverip=192.168.0.1
```

bdinfo Provides basic information on the board, such as:

- ◆ Flash memory range (address and size)
- ◆ Ethernet MAC address
- ◆ IP address
- ◆ UART baud rate

Here is an example of the board information provided by the `bdinfo` command:

```
lm32# bdinfo
boot_params = 0x00000000
memstart    = 0x00000000
memsize     = 0x00000000
flashstart  = 0x04000000
flashsize   = 0x02000000
flashoffset = 0x00000000
ethaddr     = 92:68:00:10:00:00
ip_addr     = 192.168.0.100
baudrate    = 115200 bps
```

The U-Boot startup banner provides comprehensive information on the board configuration. Following is a sample banner:

```
U-Boot 1.2.0 (Jan 27 2008 - 23:39:54) [Theobroma Systems]
```

```
LatticeMico32 board configuration:
```

| Device | Base Address | Additional information |
|-------------|--------------|------------------------|
| CPU 0 | | Frequency: 75000000 Hz |
| Flash 0 | 0x04000000 | Size: 33554432 (32 MB) |
| DDR SDRAM 0 | 0x08000000 | Size: 67108864 (64 MB) |
| Timer 0 | 0x80002000 | |

```

Timer 1          | 0x80010000 |
Timer 2          | 0x80012000 |
UART 0           | 0x80000000 | Baud Rate: 115200
LEDs 0           | 0x80004000 |
7Segment 0      | 0x80006000 |
TriSpeedMAC 0   | 0x80008000 |

```

LM32 configuration options:

```

Hardware multiplier:      enabled
Hardware divider:        enabled
Hardware barrel-shifter: enabled
Sign-extension instructions: disabled
Cycle counter CSR:       disabled
Instruction cache:       enabled
Data cache:              enabled

```

lm32mac version 0x10000 @ 0x80008000

lm32MAC#0

In: serial

Out: serial

Err: serial

Networking Environment Variables

The environment variables shown in Table 2 are used to configure the network interface in U-Boot.

Table 2: Networking Environment Variables

| Variable | Description |
|----------|--|
| ethaddr | Sets the MAC address of the Ethernet interface (for example, 12:34:56:78:ab:cd). |
| ipaddr | Sets the IP address of the Ethernet interface (for example, 192.168.0.100). |
| netmask | Sets the net mask (for example, 255.255.0.0). |
| serverip | Sets the IP address of the server on which the TFTP server resides, that is, the server from which the binaries are fetched. |

Changes made to the configuration are applied instantly.

Note

You can reset the ethaddr environment variable only once for each board. If the MAC address has been changed once, U-Boot will refuse further change requests. See “Changing the Ethernet MAC Address” on page 15 for instructions on changing the MAC address.

The dhcp U-Boot command for obtaining the configuration from a network DHCP server is not available in this build. You must configure the network interface manually.

Example Configuration

The board's network interface configuration depends on the network setup of your environment, so only an example configuration can be given at this point. You will probably have to adapt the parameters to suit your network setup.


Here is an example configuration with an IP address of 192.168.0.100, a net mask of 255.255.255.0, and a server IP address of 192.168.0.1:

```
lm32# setenv ipaddr 192.168.0.100
lm32# setenv netmask 255.255.255.0
lm32# setenv serverip 192.168.0.1
lm32# saveenv
```

You can use the ping command in U-Boot to verify connectivity to the server. However, U-Boot does not reply to ping requests, so you cannot ping the LatticeMico32 board running U-Boot from the server.

Figure 7 shows the configuration of the example network interface.

Figure 7: Example Network Interface Configuration

A screenshot of a PuTTY terminal window titled 'COM3 - PuTTY'. The window shows the U-Boot boot process. It starts with hardware initialization: DDR SDRAM (0x08000000, 64 MB), three timers (0x80002000, 0x80010000, 0x80012000), UART (0x80000000, Baud Rate: 115200), LEDs (0x80004000), 7Segment (0x80006000), and TriSpeedMAC (0x80008000). It then displays 'LM32 configuration options' with a list of features: Hardware multiplier (enabled), Hardware divider (enabled), Hardware barrel-shifter (enabled), Sign-extension instructions (disabled), Cycle counter CSR (disabled), Instruction cache (enabled), and Data cache (enabled). Next, it shows 'lm32mac version 0x10000 @ 0x80008000' and 'lm32MAC#0'. The network configuration is shown: 'In: serial', 'Out: serial', 'Err: serial'. The user enters the commands: 'lm32# setenv ipaddr 192.168.0.100', 'lm32# setenv netmask 255.255.255.0', 'lm32# setenv serverip 192.168.0.1', and 'lm32# saveenv'. The terminal then shows 'Saving Environment to Flash...', 'Un-Protected 1 sectors', 'Erasing Flash...', '. done', 'Erased 1 sectors', 'Writing to Flash... done', and 'Protected 1 sectors'. The prompt 'lm32#' is visible at the bottom with a green cursor.

Changing the Ethernet MAC Address

The default Ethernet MAC address for the LatticeMico32 Tri-Speed MAC is 12:34:56:78:ab:cd. You can override this default MAC address by setting the ethaddr environment variable. For example, to set the MAC address to 02:00:01:02:03:04, enter the following command:

```
setenv ethaddr 02:00:01:02:03:04
```

Once you change the default MAC address and save the environment variables with the saveenv command, you cannot program another MAC address by simply using the setenv ethaddr command.

To change a programmed MAC address for the LatticeECP2 board:

1. Unlock the last sector (sector 127) of the CFI flash bank 1 by using the following command:

```
protect off 1:127
```

You can use the flinfo command in U-Boot to obtain CFI flash information for the LatticeECP2 board's CFI flash configuration if your board's flash configuration is different.

2. Erase the last sector using the following command:

```
erase 1:127
```

3. Restart U-Boot, which will use the default settings. Now you can re-program the MAC address. After you erase the flash, all environment variables are erased, so you must reprogram the environment variables that you explicitly set earlier.

Writing U-Boot into Flash Memory

Starting U-Boot from flash memory eliminates the need to use GDB and TCP2JTAGVC2 every time the board is power-cycled.

To use TFTP to write U-Boot to flash memory once it is running:

1. To obtain the U-Boot binary through the TFTP server, copy the u-boot.bin file, which is the stripped U-Boot binary, to the TFTP /lm32linux/ directory, if you have not already.
2. Set the serverip environment variable, if you have not already.
3. Load the U-Boot binary into an empty section of SRAM by using the tftp command. The following example shows the binary loaded to the 0x08000000 address, since it is the base address of the SRAM and the subsequent region should be empty.

```
lm32# tftp 08000000 /lm32linux/u-boot.bin
```

4. Erase the first two sections of the flash memory (0x04000000 to 0x0407FFFF) to which the binary will be stored by using the erase command:

```
lm32# erase 04000000 0407ffff
```


5. Copy the binary from the address that you have loaded in SRAM (0x08000000) to its destination at the beginning of the flash memory by using the cp.b command:

```
lm32# cp.b 08000000 04000000 00080000
```

This command copies 0x80000 bytes, starting at 0x08000000 (SRAM base address) and ending at 0x04000000 (flash memory base address)

Figure 8 shows the process of writing U-Boot into flash memory.

Figure 8: Writing U-Boot into Flash Output



```
COM3 - PuTTY
lm32#
lm32# tftp 08000000 /lm32linux/u-boot.bin
Using lm32MAC#0 device
TFTP from server 192.168.0.1; our IP address is 192.168.0.100
Filename '/lm32linux/u-boot.bin'.
Load address: 0x8000000
Loading: #####
done
Bytes transferred = 107964 (1a5bc hex)
lm32#
lm32# erase 04000000 0407ffff
.. done
Erased 2 sectors
lm32#
lm32# cp.b 08000000 04000000 00080000
Copy to Flash... done
lm32#
```

Starting U-Boot from Flash Memory

If you have the FPGA bitstream programmed in the SPI flash, power-cycle the board or press the Program button, then press the Reset button on the LatticeECP2 board to start U-Boot automatically from flash memory.

U-Boot's early initialization assembler code copies the boot loader to the 0x0C0DC000 address in SRAM and starts it from there each time that you reset the board.

Booting the Linux Port to LatticeMico32

Now that U-Boot will start each time the board is reset, you are ready to boot the Linux port to the LatticeMico32 kernel by using the TFTP server.

At first, the boot options for the Linux kernel must be set in U-Boot. Then the kernel image and the initial RAM disk (initrd) are loaded from TFTP into the RAM and started directly from there. Although this process is enough to run Linux, you will program both images into the flash memory to run Linux independently of the TFTP server.

Setting Kernel Boot Options in U-Boot

The Linux kernel can use information given in the form of command-line options at boot time. You set the boot parameters by modifying the `bootargs` environment variable in U-Boot. The boot loader provides the contents of this variable to the kernel at start-up. Like other environment variables, this one is permanently saved when you use the `saveenv` command.

The Linux kernel parameters to be set depend on the present environment setup. You may have to adapt the parameters given in this document to be compatible with your setup. You can find a brief introduction to other useful kernel boot options in the “Linux LatticeMico32 Kernel Boot Options (bootargs)” section of the *Linux Port to LatticeMico32 System Reference Guide*.

To load the kernel and the initial RAM disk from TFTP into RAM, set the boot options in U-Boot as follows:

```
lm32# setenv bootargs 'root=/dev/ram0
ip=192.168.0.100:192.168.0.1:192.168.0.1:255.255.255.0:::
console=ttyS0,115200 ramdisk_size=16384'
```

The first kernel parameter, `root`, tells the kernel that the `ram0` device (that is, the RAM) will be used as the root file system while booting. The second parameter, `ip`, tells the kernel how to configure the network interface. It uses a colon-separated list of seven arguments in the following order:

- ◆ IP address for the local interface (192.168.0.100, as before)
- ◆ IP address of the server (192.168.0.1)
- ◆ IP address of the gateway (192.168.0.1)
- ◆ Net mask for the local interface (255.255.255.0)
- ◆ Host name (default value)
- ◆ Name of the network device (default value)
- ◆ Auto-configuration (default: none)

If you would like to use a DHCP server to obtain an IP configuration, set the `ip` parameter to `dhcp` (that is, `ip=dhcp`) as shown below:

```
lm32# setenv bootargs 'root=/dev/ram0 ip=dhcp
console=ttyS0,115200 ramdisk_size=16384'
```

Note

If the LatticeECP2 board is not connected to a network with a DHCP server, the kernel will repeatedly perform DHCP requests for obtaining an IP address

The parameter `console` is used to tell the kernel which device will be used as the first virtual terminal, that is, the device to which the boot messages are printed. To use the board's `ttyS0` serial port with a baud rate of 115200, set this parameter to `ttyS0,115200`. Finally, set the maximum size of the initial RAM disk with the `ramdisk_size` parameter. To be on the safe side, use a size of 16384 kB, even though the distributed `initrd.img` file is probably smaller.

Loading the Kernel and the Initial RAM Disk Through TFTP

You must configure U-Boot to load the kernel image and the initial RAM disk from TFTP to fixed locations in RAM and use these locations to boot from. Use the `bootcmd` environment variable in U-Boot to perform this configuration.

Set the `bootcmd` environment variable and its parameters as in this example:

```
lm32# setenv bootcmd 'tftp 0x08200000 /lm32linux/vmlinux.img;  
tftp 0x08400000 /lm32linux/initrd.img;  
bootm 08200000 08400000'
```

In this example, the `bootcmd` environment variable includes three single U-Boot parameters:

- ◆ The first one (`tftp 0x08200000 /lm32linux/vmlinux.img;`) downloads the `vmlinux.img` kernel image from the TFTP server directly to RAM at the `0x08200000` address.
- ◆ The second one (`tftp 0x08400000 /lm32linux/initrd.img;`) downloads the initial RAM disk `initrd.img` to the `0x08400000` RAM address.
- ◆ The third command (`bootm 08200000 08400000`) instructs the kernel to boot from memory at the `0x08200000` address and use the initial RAM disk at `0x08400000`.


These commands are executed in order right after the boot command is executed or the board is reset. If the `bootcmd` environment variable is set and permanently saved to flash memory with the `saveenv` command, the boot command will be executed automatically each time the board is reset after starting the boot loader.

After setting the `bootcmd` environment variable and parameters, save the configuration by using the `saveenv` command:

```
lm32# saveenv
```

Figure 9 summarizes this procedure.

Figure 9: Setting Boot Command and Options



```
COM3 - PuTTY
Timer 0      | 0x80002000 |
Timer 1      | 0x80010000 |
Timer 2      | 0x80012000 |
UART 0      | 0x80000000 |
LEDS 0      | 0x80004000 |
7Segment 0  | 0x80006000 |
Tr1SpeedMAC 0 | 0x80008000 |


LM32 configuration options:
Hardware multiplier:  enabled
Hardware divider:    enabled
Hardware barrel-shifer:  enabled
Sign-extension instructions: disabled
Cycle counter CSR:    disabled
Instruction cache:    enabled
Data cache:          enabled

lm32mac version 0x10000 @ 0x80008000
lm32MAC#0
In:  serial
Out: serial
Err: serial
lm32#
lm32# setenv bootargs 'root=/dev/ram0 ip=192.168.0.100:192.168.0.1:192.168.0.1:255.255.255.
0::: console=ttyS0,115200 ramdisk_size=16384'
lm32# setenv bootcmd 'tftp 0x08200000 /lm32linux/vmlinux.img; tftp 0x08400000 /lm32linux/in
itrd.img; bootm 08200000 08400000'
lm32# saveenv
Saving Environment to Flash...
Un-Protected 1 sectors
Erasing Flash...
. done
Erased 1 sectors
Writing to Flash... done
Protected 1 sectors
lm32#
```

Booting the Kernel

The U-Boot boot command reads the bootargs and bootcmd environment variables and follows the instructions given. Provided that both variables are set correctly, the boot command should successfully initiate the downloading of the images and the Linux kernel boot process, as shown in Figure 10.

Figure 10: U-Boot Downloading the Images

A screenshot of a PuTTY terminal window titled 'COM3 - PuTTY'. The window shows the output of a U-Boot boot process. The text is as follows:


```
TriSpeedMAC 0 | 0x80008000 |
LM32 configuration options:
Hardware multiplier:      enabled
Hardware divider:        enabled
Hardware barrel-shifer:  enabled
Sign-extension instructions: disabled
Cycle counter CSR:       disabled
Instruction cache:       enabled
Data cache:              enabled

lm32mac version 0x10000 @ 0x80008000
lm32MAC#0
In: serial
Out: serial
Err: serial
Hit any key to stop autoboot: 0
Using lm32MAC#0 device
TFTP from server 192.168.0.1; our IP address is 192.168.0.100
Filename '/lm32linux/vmlinux.img'.
Load address: 0x8200000
Loading: #####
#####
done
Bytes transferred = 976228 (ee564 hex)
Using lm32MAC#0 device
TFTP from server 192.168.0.1; our IP address is 192.168.0.100
Filename '/lm32linux/initrd.img'.
Load address: 0x8400000
Loading: #####
#####
#####
#####
#####
```

If you saved the environment variables by using the saveenv command, the kernel will start automatically after resetting the board and after a short waiting period to enable you to interrupt the boot process, if needed.

The kernel boot process produces many lines of debug and status output. After that, a login shell appears, as shown in Figure 11. Use login name “root” and password “lattice” to log in as a root user.

Figure 11: Linux Login Prompt



```
COM3 - PuTTY
Shell invoked to run file: /etc/rc
Command:
Command: hostname lm32_eval_evp250
Command:
Command: mount -t proc proc /proc
Command:
Command: mount -t sysfs sysfs /sys
Command:
Command: mount / -o remount,rw
Command:
Command: chmod -R a+r /var/www
Command:
Execution Finished, Exiting

lm32_eval_evp250 login: root
Password:
Welcome to Linux on LatticeMico32!

theobroma systems

For further information check:
http://www.theobroma-systems.com/mico32/
http://www.latticesemi.com/

Jan 1 00:02:59 login[20]: root login on 'ttyS0'

BusyBox v1.7.1 (2007-11-02 15:57:34 CET) built-in shell (msh)
Enter 'help' for a list of built-in commands.

root:~#
```

Programming the Images into Flash Memory (Optional)

Each time that you reset the board or execute the U-Boot boot command, the kernel and the RAM disk images are loaded from TFTP to the board's RAM. This process is not only very time-consuming but also requires that the TFTP server always be present. For this reason, you will now program the two images permanently to flash memory and start the kernel from there.

Starting the Kernel from Flash Memory

To start the kernel from flash memory:

1. Reset the board and press any key to stop the automatic boot function, as shown in Figure 12.

You should see the U-Boot prompt.

Figure 12: Stopping the U-Boot Automatic Boot Feature

```

COM3 - PuTTY
U-Boot 1.2.0 (Nov 14 2007 - 12:27:07) [Theobroma Systems]

LatticeMico32 board configuration:
-----
Device          | Base Address | Additional information
-----
CPU 0           | 0x04000000   | Frequency: 75000000 Hz
Flash 0         | 0x04000000   | Size: 33554432 (32 MB)
DDR SDRAM 0     | 0x08000000   | Size: 67108864 (64 MB)
Timer 0         | 0x80002000
Timer 1         | 0x80010000
Timer 2         | 0x80012000
UART 0          | 0x80000000   | Baud Rate: 115200
LEDs 0          | 0x80004000
7Segment 0     | 0x80006000
TriSpeedMAC 0  | 0x80008000

LM32 configuration options:
Hardware multiplier:  enabled
Hardware divider:    enabled
Hardware barrel-shifer:  enabled
Sign-extension instructions: disabled
Cycle counter CSR:    disabled
Instruction cache:    enabled
Data cache:          enabled

lm32mac version 0x10000 @ 0x80008000
lm32MAC#0
In:  serial
Out: serial
Err: serial
Hit any key to stop autoboot: 0
lm32#
  
```

Note

See “Configuring the Automatic Boot Delay” on page 27 for information on changing the automatic boot delay.

- Download the kernel image to RAM by using U-Boot:

```
lm32# tftp 08000000 /lm32linux/vmlinux.img
```

Only the region at the end of the RAM is used in U-Boot, so you can even use the RAM regions at the very beginning for copying.

- To verify that the downloaded data is correct, enter the following command:

```
iminfo 08000000
```

The system now prints a number of lines containing information on the image type. If the data is correct, you will see `Verifying Checksum . . . OK` on the last line. If the data is not correct, you will see `Verifying Checksum . . . BAD` on the last line.

- Since the U-Boot already resides in the first two sectors from 0x04000000 to 0x0403FFFF, you must write the kernel to an adjacent region. Choose 0x04040000. Since the kernel image is compressed, you must only erase the next five sectors:

```
lm32# erase 04040000 0417ffff
```

- Use the following command to copy the kernel image from the RAM to the emptied flash sectors:

```
cp.b <from> <to> <length>
```

Here is an example of the `cp.b` command:


```
lm32# cp.b 08000000 04040000 0x120000
```

- To start the kernel from flash memory, you must modify the boot commands, as shown in the following example and in Figure 13:

```
lm32# setenv bootcmd 'tftp 0x08400000 /lm32linux/initrd.img;
bootm 04040000 08400000'
```

Now the initial RAM disk image comes through TFTP, but the kernel is already loaded directly from the 0x04040000 address in the flash memory.

Figure 13: Writing the Kernel to Flash Memory and Modifying the Boot Commands



```
COM1 - PuTTY
lm32# tftp 08000000 /lm32linux/vmlinux.img
Using lm32MAC#0 device
TFTP from server 192.168.0.1:our IP address is 192.168.0.100
Filename '/lm32linux/vmlinux.img'.
Load address: 0x8000000
Loading: #####
#####
#####
#####
done
Bytes transferred = 1152379 (11957b hex)
lm32# iminfo 08000000

## Checking Image at 08000000 ...
Image Name: Lattice Linux U-Boot Image
Image Type: LatticeMico32 Linux Kernel Image (gzip compressed)
Data Size: 1152315 Bytes = 1.1 MB
Load Address: 08000000
Entry Point: 08000000
Verifying Checksum ... OK
lm32# erase 04040000 0417ffff

.... done
Erased 5 sectors
lm32# cp.b 08000000 04040000 0x120000
Copy to Flash... done
lm32# setenv bootcmd 'tftp 0x08400000 /lm32linux/initrd.img; bootm 04040000 08400000'
lm32# saveenv
Saving Environment to Flash...
Un-Protected 1 sectors
Erasing Flash...
. done
Erased 1 sectors
Writing to Flash... done
Protected 1 sectors
lm32#
```

- Type **saveenv**, **boot**, or both to test the new setup; that is, start the kernel from flash memory.

Writing the Initial RAM Disk to Flash Memory

To write the initial RAM disk to flash memory:

- If you have started the kernel to test the setup, reset the board and press any key to stop the automatic boot function.

- Download the initial RAM disk image to RAM by using U-Boot:

```
lm32# tftp 08000000 /lm32linux/initrd.img
```

- To verify that the downloaded data is correct, enter the following command:

```
imininfo 08000000
```

The system now prints a number of lines containing information on the image type. If the data is correct, you will see `Verifying Checksum ... OK` on the last line. If the data is not correct, you will see `Verifying Checksum ... BAD` on the last line.

- Since the region 0x04000000 to 0x0417FFFF is already reserved for U-Boot and the kernel image, you will save the RAM disk image to 0x04240000. The maximum size of the RAM disk image is 0x01000040 (16 MB plus a 64-byte header), so you must erase the adjacent 0x01040000 bytes (65 sectors) of the flash memory:

```
lm32# erase 04240000 0527ffff
```

- Use the following command to copy the image from RAM to the flash sectors:

```
cp.b <from> <to> <length>
```

Here is an example:

```
lm32# cp.b 08000000 04240000 01040000
```

This task is very time-consuming and will take about 20 to 30 minutes to complete.


- Because the kernel cannot use the RAM disk image directly from flash memory, you must copy the image from flash to RAM before booting the kernel. Use the U-Boot boot commands for this purpose:

```
lm32# setenv bootcmd 'ping 1.1.1.1; cp.b 04240000 08400000 01000040;
bootm 04040000 08400000'
```

The ping command attempts to ping address 1.1.1.1, which is non-existent, so it fails when booting Linux, as shown in Figure 14. However, it allows U-Boot to set up the address of the Tri-Speed MAC.

This command copies the RAM disk to 0x08400000, since the region 0x08000000 to 0x08400000 is used by the Linux kernel at run time.

Figure 14: Failure of the Ping Command



- Type `saveenv`, `boot`, or both to test the new setup; that is, start the kernel and use the initial RAM disk from the flash memory.

Figure 15 shows these transactions.

Configuring the Automatic Boot Delay

You can change the automatic boot delay at run time.

To change the automatic boot delay:

1. Specify the new automatic boot delay by entering the following:

```
setenv bootdelay <number_of_seconds>
```

Here is an example that sets the automatic boot delay to 10 seconds:

```
setenv bootdelay 10
```

2. Save this configuration by entering the following:

```
saveenv
```

3. Verify the setting by printing the environment variable:

```
printenv
```

To configure the default automatic boot delay for the U-Boot build:

1. Edit the ECP250full.h header file, which is located in the u-boot/include/configs/ directory under the sources installation directory, to modify the following preprocessor definition, as in this example:

```
#define CONFIG_BOOTDELAY    5
```

2. Rebuild U-Boot.


Testing the Setup

You should now have a board that starts U-Boot and boots the Linux kernel with the initial RAM disk file system automatically after a power cycle or a reset. Now you are free to test and evaluate the Linux port to LatticeMico32 however you want to. Following are brief descriptions of the tools that you can use in testing and evaluating the Linux port to LatticeMico32.

telnet

Instead of using the serial port to operate with the board, you can use telnet. If you connect your telnet client (for example, telnet 192.168.0.100, using the default telnet port 23), the Linux login shell appears. Log in as user “root” and provide the default root password, “lattice.” After you log in, the BusyBox built-in shell (msh) appears, which is quite similar to bash, as shown in Figure 16.

Figure 16: Logging In by Using Telnet



```
ca Telnet
lm32_eval_eep250 login: root
Password:
Welcome to Linux on LatticeMico32!

theobroma systems

For further information check:
http://www.theobroma-systems.com/mico32/
http://www.latticesemi.com/

BusyBox v1.7.1 (2007-11-15 12:13:38 CET) built-in shell (msh)
Enter 'help' for a list of built-in commands.

root:~#
```

Userland Application

Once you log in, a variety of userland applications are available. Use the following command to see a list of all applications available in the current release:

```
ls /bin /usr/bin
```

HTTP Server

After you log in, the current working directory of the shell is the root account's home directory, /root. Located in this directory is a shell script named http_server.sh, which starts the built-in tftpd (HTTP) server. Start the server by running this script:


```
root:~# ./http_server.sh
```

As long as the script is running, the HTTP server is available. You can stop the server (and therefore the script) by pressing **Ctrl-C**.

Start your preferred Web browser and open URL <http://192.168.0.100/>.

If the server has been started successfully, a test Web page should be provided by the board, as shown in Figure 17.


Figure 17: HTTP Server Test Web Page



LED Switch Web Application

This section demonstrates how to use a Web application running on Linux to perform hardware-related tasks. Start the HTTP server using the `http_server.sh` script, start your Web browser, and open the URL http://192.168.0.100/cgi-bin/lm32_leds.cgi. A demonstration Web application for turning the board's LEDs on or off should appear, as shown in Figure 18. Click the switch links to switch the state of the corresponding LED.

Figure 18: HTTP Server LED Switch Web Application



LED Switch Command-Line Application

Open two telnet connections to the board and log in to both. In the first telnet window, start the `lm32_led_server` application, shown in Figure 19, which represents a server application that awaits commands from a client to control the board's LEDs. In the second window, run `lm32_led_client`, shown in Figure 20, without a parameter to get the usage message:

```
root:~# lm32_led_client
LatticeMico32 Command-Line LED Demo - Client
Usage:
  lm32_led_client index [on|off]
```

Switch LED with the given index on or off. If no state is given, the LED state is set to the opposite of its current state.

Use this client to communicate with the server. The first parameter defines the LED's index. If no second parameter is given, the LED state is set to the

opposite of its current state. To explicitly set the state, use the second parameter: on tells the server to set the LED, and off tells the server to turn the LED off.

Here are some example client calls:


```
root:~# lm32_led_client 3 off
root:~# lm32_led_client 3
root:~# lm32_led_client 3 on
root:~# lm32_led_client 3
root:~# lm32_led_client 2
root:~# lm32_led_client 7 off
root:~# lm32_led_client 7 on
root:~# lm32_led_client 0
root:~# lm32_led_client 0 on
```

Following is an example of output from the server:


```
root:~# lm32_led_server
Switched LED 3 off.
Switched LED 3 on.
State of LED 3 unchanged.
Switched LED 3 off.
Switched LED 2 off.
Switched LED 7 off.
Switched LED 7 on.
Switched LED 0 off.
Switched LED 0 on.
```

Close the server by pressing **Ctrl-C**.

Figure 19: LED Switch Command-Line Server

A screenshot of a Telnet window titled "Telnet 192.168.0.100". The window shows a command-line interface with the following text:

```
root:~# lm32_led_server
Switched LED 3 off.
Switched LED 3 on.
State of LED 3 unchanged.
Switched LED 3 off.
Switched LED 2 off.
Switched LED 7 off.
Switched LED 7 on.
Switched LED 0 off.
Switched LED 0 on.
```

Figure 20: LED Switch Command-Line ClientA screenshot of a Telnet window titled "Telnet 192.168.0.100". The window shows a root shell prompt with several commands and their outputs. The commands are: "lm32_led_client 3 off", "lm32_led_client 3", "lm32_led_client 3 on", "lm32_led_client 3", "lm32_led_client 2", "lm32_led_client 7 off", "lm32_led_client 7 on", "lm32_led_client 0", and "lm32_led_client 0 on". The prompt returns to root:~# after each command.

```
root:~# lm32_led_client 3 off
root:~# lm32_led_client 3
root:~# lm32_led_client 3 on
root:~# lm32_led_client 3
root:~# lm32_led_client 2
root:~# lm32_led_client 7 off
root:~# lm32_led_client 7 on
root:~# lm32_led_client 0
root:~# lm32_led_client 0 on
root:~#
```

More Information

This section gives links to additional information on the topics in this document.

For more information on the GCC tool chain and the GDB debugger, go to:

<http://www.gnu.org>

For more information on uClinux, go to:

<http://www.uclinux.org>

For more information on Linux, go to:

- ◆ <http://www.linux.org>
- ◆ <http://kernel.org>

Index

A

automatic boot delay **27**

B

bash shell **28**
bdinfo command **13**
binary distribution tarball **3, 4**
boot command **21, 22**
boot delay **27**
bootargs environment variable **18, 21**
bootcmd environment variable **19, 21**
BusyBox built-in shell **28**

C

COM port **7, 9**
Cygwin **2**

D

dhcp command **14**
DHCP server **14, 18**
downloading bitstream to FPGA **5**

E

ethaddr environment variable **14, 15**
Ethernet MAC address **13, 14, 15**

F

flash memory
 starting Linux kernel from **22**
 starting U-Boot from **17**
 writing initial RAM disk to **24**
 writing U-Boot to **16**
flinfo command **16**

G

GDB **5, 10, 16**

H

HTTP server **28**
http_server.sh script **30**
HyperTerminal **3, 9**

I

iminfo command **23, 24**
initrd.img image **5, 18, 19**
IP address **14**
ip parameter **18**
ipaddr environment variable **12, 14**
ispVM System **2**

J

JTAG debugging **5, 12**
JTAG debugging executable **11**
JTAG interface **6, 11**

L

LED switch command-line application **30**
LED switch Web application **30**
Linux kernel
 booting **21**
 loading image and RAM disk **19**
 setting boot options in U-Boot **17**
 starting from flash memory **22**
Linux port to LatticeMico32 **17**
lm32-elf-gdb **2**
logging in as root **22**

M

MAC address see Ethernet MAC address

MSBplatform.msb file **4, 5**
msh shell **28**

N

net mask **14**
netmask environment variable **14**
network interface **12**

P

Picocom **3**
platform.bit file **4, 5**
pre-generated bitstream **1**

- components and memory layout **5**
- downloading to FPGA **5, 6**
- using ispVM System to download to board **2**

printenv command **13**
PuTTY

- output of U-Boot start-up sequence **12**
- setting up to load U-Boot **7**
- source **3**

PuTTY Configuration dialog box **7, 8**
putty.exe file **7**

R

RAM disk

- initrd.img image **5, 19**
- loading from TFTP to RAM **17, 19, 22**
- setting size of initial **18**
- writing to flash memory **24**

ramdisk_size kernel parameter **18**
README file **4**
remote serial console **3, 7**
root kernel parameter **18**
RS-232 connection **3, 6, 7**

S

saveenv command **12, 18, 19, 21**
SDK shell **2, 3, 4, 9**
serial console **3, 7**
serverip environment variable **14, 16**
setenv command **12**

T

TCP2JTAGVC2 **2, 11, 16**
telnet **28**
TFTP server

- booting Linux port to LatticeMico32 **17**
- downloading files from tarball **5**
- IP address **14**
- IP address of **2**
- obtaining U-Boot binary **12, 16**
- purpose **2**
- setting up with Cygwin **2**
- sources **2**

thttpd HTTP server **28**

U

U-Boot

- checking settings of environment variables **13**
- configuring network interface **12**
- downloading initial RAM disk image **24**
- environment variables available in **14**
- loading **6**
- loading into RAM **9**
- loading kernel image and RAM disk **19**
- pre-built **3, 5**
- remote serial console **3**
- requirements for copying to board **2**
- setting environment variables **12**
- setting kernel boot options **18**
- source of information on **6**
- starting from flash memory **17**
- starting from RAM **11**
- stripped binary to program into flash memory **4**
- unstripped binary for JTAG debugging **4**
- uploading JTAG debugging executable **11**
- writing to flash memory **16**

u-boot file **4**
u-boot.bin file **4, 5, 16**
userland applications **28**

V

vmlinux file **5**
vmlinux.img image **5, 19**